

ABSSRS_BMW_V6.00 Function List (Note:For reference only)

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle. ▲ This function is the new feature in this version.

Series	Model Series	Part	Systems
1 Series	E81/E82/E87/E88	Body	MRS/AB Airbag/ACSM
1 Series	E81/E82/E87/E88	Chassis	ABS/ASC/DSC Dynamic Stability Control
3 Series	E30	Body	AB (airbag)
3 Series	E30	Chassis	ABS (Anti-lock braking system)\n ASC (Automatic stability control)\n ABD (Automatic brake differential (All-wheel drive))\n DSC (Dynamic stability control ('94->))
3 Series	E30	Chassis	DSC (Dynamic stability control)
3 Series	E30	Chassis	ABS/ASC tester
3 Series	E36[<9803]	Body	AB (airbag)
3 Series	E36[<9803]	Chassis	ABS (Anti-lock braking system)\n ASC (Automatic stability control)\n ABD (Automatic brake differential (All-wheel drive))\n DSC (Dynamic stability control ('94->))
3 Series	E36[<9803]	Chassis	DSC (Dynamic stability control)
3 Series	E36[<9803]	Chassis	ABS/ASC tester
3 Series	E36[>9803]	Body	MRS/AB Airbag/ACSM
3 Series	E36[>9803]	Chassis	ABS/ASC/DSC Dynamic Stability Control
3 Series	E46	Body	MRS/AB Airbag/ACSM
3 Series	E46	Chassis	ABS/ASC/DSC Dynamic Stability Control
3 Series	E90/E91/E92/E93	Body	MRS/AB Airbag/ACSM
3 Series	E90/E91/E92/E93	Chassis	ABS/ASC/DSC Dynamic Stability Control
5 Series	E28	Body	AB (airbag)
5 Series	E28	Chassis	ABS (Anti-lock braking system)\n ASC (Automatic stability control)\n ABD (Automatic brake differential (All-wheel drive))\n DSC (Dynamic stability control ('94->))
5 Series	E28	Chassis	DSC (Dynamic stability control)
5 Series	E28	Chassis	ABS/ASC tester
5 Series	E34	Body	AB (airbag)
5 Series	E34	Chassis	ABS (Anti-lock braking system)\n ASC (Automatic stability control)\n ABD (Automatic brake differential (All-wheel drive))\n DSC (Dynamic stability control ('94->))
5 Series	E34	Chassis	DSC (Dynamic stability control)
5 Series	E34	Chassis	ABS/ASC tester
5 Series	E39	Body	MRS/AB Airbag/ACSM
5 Series	E39	Chassis	ABS/ASC/DSC Dynamic Stability Control
5 Series	E60/E61	Body	MRS/AB Airbag/ACSM

Series	Model Series	Part	Systems
5 Series	E60/E61	Chassis	ABS/ASC/DSC Dynamic Stability Control
6 Series	E24	Body	AB (airbag)
6 Series	E24	Chassis	ABS (Anti-lock braking system)\n ASC (Automatic stability control)\n ABD (Automatic brake differential (All-wheel drive))\n DSC (Dynamic stability control ('94->))
6 Series	E24	Chassis	DSC (Dynamic stability control)
6 Series	E24	Chassis	ABS/ASC tester
6 Series	E63/E64	Body	MRS/AB Airbag/ACSM
6 Series	E63/E64	Chassis	ABS/ASC/DSC Dynamic Stability Control
7 Series	E23	Body	AB (airbag)
7 Series	E23	Chassis	ABS (Anti-lock braking system)\n ASC (Automatic stability control)\n ABD (Automatic brake differential (All-wheel drive))\n DSC (Dynamic stability control ('94->))
7 Series	E23	Chassis	DSC (Dynamic stability control)
7 Series	E23	Chassis	ABS/ASC tester
7 Series	E32	Body	AB (airbag)
7 Series	E32	Chassis	ABS (Anti-lock braking system)\n ASC (Automatic stability control)\n ABD (Automatic brake differential (All-wheel drive))\n DSC (Dynamic stability control ('94->))
7 Series	E32	Chassis	DSC (Dynamic stability control)
7 Series	E32	Chassis	ABS/ASC tester
7 Series	E38	Body	MRS/AB Airbag/ACSM
7 Series	E38	Chassis	ABS/ASC/DSC Dynamic Stability Control
7 Series	E65	Chassis	ABS/ASC/DSC Dynamic Stability Control
8 Series	E31	Body	AB (airbag)
8 Series	E31	Chassis	ABS (Anti-lock braking system)\n ASC (Automatic stability control)\n ABD (Automatic brake differential (All-wheel drive))\n DSC (Dynamic stability control ('94->))
8 Series	E31	Chassis	DSC (Dynamic stability control)
8 Series	E31	Chassis	ABS/ASC tester
X3 Series	E83	Body	MRS/AB Airbag/ACSM
X3 Series	E83	Chassis	ABS/ASC/DSC Dynamic Stability Control
X5 Series	E53	Body	MRS/AB Airbag/ACSM
X5 Series	E53	Chassis	ABS/ASC/DSC Dynamic Stability Control
X5 Series	E70	Body	MRS/AB Airbag/ACSM
X5 Series	E70	Chassis	ABS/ASC/DSC Dynamic Stability Control
X6 Series	E71	Body	MRS/AB Airbag/ACSM
X6 Series	E71	Chassis	ABS/ASC/DSC Dynamic Stability Control
Z Series	E30	Body	AB (airbag)
Z Series	E30	Chassis	ABS (Anti-lock braking system)\n ASC (Automatic stability control)\n ABD (Automatic brake differential (All-wheel drive))\n DSC (Dynamic stability control ('94->))

Series	Model Series	Part	Systems
Z Series	E30	Chassis	DSC(Dynamic stability control)
Z Series	E30	Chassis	ABS/ASC tester
Z3 Series	E36	Body	MRS/AB Airbag/ACSM
Z3 Series	E36	Chassis	ABS/ASC/DSC Dynamic Stability Control
Z4 Series	E85/E86	Body	MRS/AB Airbag/ACSM
Z4 Series	E85/E86	Chassis	ABS/ASC/DSC Dynamic Stability Control
Z8 Series	E52	Body	MRS/AB Airbag/ACSM
Z8 Series	E52	Chassis	ABS/ASC/DSC Dynamic Stability Control
Z Reihe	Z4_E89	Chassis	ABS/ASC/DSC Dynamic Stability Control
Z Reihe	Z4_E89	Body	MRS/AB Airbag/ACSM
1 Series	F20	Chassis	DSC Dynamic Stability Control
1 Series	F20	Body	ACSM Crash Safety Module
3 Series	F30	Chassis	DSC Dynamic Stability Control
3 Series	F30	Body	ACSM Crash Safety Module
5 Series	F07	Chassis	DSC Dynamic Stability Control
5 Series	F07	Body	ACSM Crash Safety Module
5 Series	F10/F11	Chassis	DSC Dynamic Stability Control
5 Series	F10/F11	Body	ACSM Crash Safety Module
5 Series	F18	Chassis	DSC Dynamic Stability Control
5 Series	F18	Body	ACSM Crash Safety Module
6 Series	F12/F13	Chassis	DSC Dynamic Stability Control
6 Series	F12/F13	Body	ACSM Crash Safety Module
7 Series	F01/F02/F04	Chassis	DSC Dynamic Stability Control
7 Series	F01/F02/F04	Body	ACSM Crash Safety Module
X3 Series	F25	Chassis	DSC Dynamic Stability Control
X3 Series	F25	Body	ACSM Crash Safety Module
X6 Series	E72	Chassis	DSC Dynamic Stability Control
X6 Series	E72	Body	ACSM Crash Safety Module
X1 Series	E84	Chassis	DSC Dynamic Stability Control
X1 Series	E84	Body	ACSM Crash Safety Module
2 Series	F22	Chassis	DSC Dynamic Stability Control
2 Series	F22	Body	ACSM Crash Safety Module
3 Series	F34	Chassis	DSC Dynamic Stability Control
3 Series	F34	Body	ACSM Crash Safety Module
4 Series	F32/F33	Chassis	DSC Dynamic Stability Control

Series	Model Series	Part	Systems
4 Series	F32/F33	Body	ACSM Crash Safety Module
4 Series	F36	Chassis	DSC Dynamic Stability Control
4 Series	F36	Body	ACSM Crash Safety Module
6 Series	F06	Chassis	DSC Dynamic Stability Control
6 Series	F06	Body	ACSM Crash Safety Module
I Series	I01/I12	Chassis	DSC Dynamic Stability Control
I Series	I01/I12	Body	ACSM Crash Safety Module
X Series	X5_F15	Chassis	DSC Dynamic Stability Control
X Series	X5_F15	Body	ACSM Crash Safety Module
X Series	X4_F26	Chassis	DSC Dynamic Stability Control
X Series	X4_F26	Body	ACSM Crash Safety Module
3 Series	F80	Chassis	DSC Dynamic Stability Control
3 Series	F80	Body	ACSM Crash Safety Module
4 Series	F82/F83	Chassis	DSC Dynamic Stability Control
4 Series	F82/F83	Body	ACSM Crash Safety Module
X Series	X5_F85	Chassis	DSC Dynamic Stability Control
X Series	X5_F85	Body	ACSM Crash Safety Module
X Series	X6_F16	Chassis	DSC Dynamic Stability Control
X Series	X6_F16	Body	ACSM Crash Safety Module
X Series	X6_F86	Chassis	DSC Dynamic Stability Control
X Series	X6_F86	Body	ACSM Crash Safety Module